

BEECHCRAFT KING AIR

90 Series - Parts in Stock

AOG: 678.357.8890

Environmental Control

System	Part Number	Description
21	100-384072-5	DRIVE MOTOR (Replaces 26501-2 Aerospace Systems & Comp)
21	103648-5	OUTFLOW VALVE 5.0 PSA (Replaces 103648-12)
21	130346-1	CONTROLLER, 4.6 PSI
21	130346-7	CONTROLLER, 5.0 PSI
21	90-384031-1	BLOWER (Electromech EM603-9)
21	97-380000-17	PNEUMOSTAT (1520T100-2)
21	97-380000-33	FLOW CONTROL VALVE (1520T100-115)

Autoflight

System	Part Number	Description
22	93A100-83	CVR
22	93A151-30	CONTROL UNIT

Electrical

System	Part Number	Description
24	23048-006	STARTER GENERATOR (50-380076-5) (250SGL16Q LUCAS)

Flight Controls

System	Part Number	Description
27	50-521152-1	FLAP ACTUATOR, LH INBOARD
27	50-521152-2	FLAP ACTUATOR, RH INBOARD
27	50-521198-3	FLAP ACTUATOR, LH OUTBOARD
27	50-521198-4	FLAP ACTUATOR, RH OUTBOARD
27	50-521223-3	FLAP ACTUATOR, LH OUTBOARD
27	50-521223-4	FLAP ACTUATOR, RH OUTBOARD
27	795-9	LIFT DETECTOR
27	99-524025-3	MOTOR, FLAP
27	99-524025-7	FLAP MOTOR & GEARBOX
27	99-524122-1	GEARBOX, FLAP

Fuel

System	Part Number	Description
28	50-389034-11	FUEL CELL
28	50-389034-12	FUEL CELL

Indicating

System	Part Number	Description
31	91-380019-1	TURB & BANK INDICATOR
31	99-384044-7	INDICATOR, PITCH TRIM STANDBY

Landing Gear

System	Part Number	Description
32	115-8001-3	BRAKE, STANDARD (2-1138 BFG)
32	115-8001-4	MAIN WHEEL FLOTATION (3-1283 OPT 2 BFS)
32	115-810000-629	LH MAIN GEAR STANDARD
32	115-810000-630	RH MAIN GEAR STANDARD
32	50-300010-133	MAIN WHEEN STANDARD (3-1208-1 OPT 1 BFS)
32	50-810164-17	RH MLG ACTUATOR
32	50-810164-18	LH MLG ACTUATOR
32	50-810304-679	LH MAIN GEAR STANDARD WITH KEYWAY
32	50-810304-680	RH MAIN GEAR STANDARD WITH KEYWAY
32	50-820196-xxx	NOSE LANDING GEAR
32	50-820208-5	ACTUATOR, NOSE GEAR MECHANICAL
32	90-380038-1	BRAKE (2-993-1 BFG)
32	91-380002-3	MOTOR
32	91-810010-5	MOTOR & GEARBOX, MLG
32	91-810010-7	GEARBOX
32	97-820000-652	STANDARD NOSE GEAR (97-820000-613)
32	99-8003-5	BRAKE FLOTATION (9544397-1 ABS)
32	99-8003-7	MAIN WHEEL FLOTATION (9544396 ABS)
32	99-8004-3	NOSE WHEEN 6.5-10 (9544061-1 ABS)
32	99-8013-5	MAIN WHEEL FLOTATION (3-1357 OPT 2 BFS)
32	99-810000-***	LH MAIN GEAR FLOTATION
32	99-810000-***	RH MAIN GEAR FLOTATION
32	99-810057-651	MAIN GEAR ACTUATOR, RH STANDARD
32	99-810057-652	MAIN GEAR ACTUATOR, RH STANDARD
32	99-810057-653	MAIN GEAR ACTUATOR, RH STANDARD
32	99-810057-654	MAIN GEAR ACTUATOR, RH STANDARD

Lighting

System	Part Number	Description
33	60-2799-1	POWER SUPPLY

Windows

System	Part Number	Description
56	101-384025-23	WINDSHIELD LH PILOT HEATED
56	101-384025-24	WINDSHIELD,RH, COPILOT HEATED
56	50-420069-**	WINDSHIELD

Props

System	Part Number	Description
61	210624	PROP GOVERNOR OVERSPEED (115-389014-3)
61	210599	PROP GOVERNOR PRIMARY (50-389077-15)
61	210631	PROP GOVERNOR OVERSPEED (115-389014-5)
61	210632	PROP GOVERNOR OVERSPEED (97-389000-3)
61	8210-002	PROP GOVERNOR PRIMARY (3011540 P & W)
61	8210-025	PROP GOVERNOR PRIMARY (3011522 P & W)
61	A210578	PROP GOVERNOR PRIMARY (50-389077-13)

Powerplant

System	Part Number	Description
71	100-389015-1	OIL COOLER (50-389048-3)
72	101-389025-5	FIREWALL FUEL SHUTOFF VALVE (EM424-8) Replaces -1 & -3)
72	109-389002-7	FUEL SHUTOFF VALVE EXCHANGE ONLY
72	3244745-2	FUEL CONTROL UNIT (3027049 P & W)
72	50-380177-5	FUEL BOOST PUMP (1D2-12 AIRBORNE)
72	50-380177-7	FUEL BOOST PUMP (1D2-13 AIRBORNE)
72	91-380003-3	FUEL PUMP RG34720F (Replaces 91-380003 Lear Romec RG34720A & C)